

WINTERIZING YOUR FINN EQUIPMENT

HYDROSEEDERS

A. Pump

1. Check impeller wear plate tolerance-adjust or replace
2. Inspect casting for wear
3. Replace seal if leaking
4. Drain water from pump casing, then pour in a quart of oil & spin by hand to prevent rust
5. Remove lubricator cup & fittings, clean & repack with soft soda based grease

B. Tank

1. Exterior can be cleaned of lime & fertilizer by spraying on fuel oil (caution-consult local ordinances) or vinegar & washing off several days later. Touch up with paint
2. Interior should be cleaned & spot painted
3. Inspect all tank bearings & seals. Replace if necessary

C. Piping

1. Inspect all rubber seals & gaskets
2. Inspect all piping clamps & coupler
3. On units with plug type discharge valves, remove & disassemble valve, clean grease grooves & the large plug in the bottom of the valve & repack
4. Flush all hoses, reels & piping



HydroSeeder Winterizing