

WINTERIZING YOUR FINN EQUIPMENT

ALL MACHINES

A. Engines

1. Change oil & oil filter
2. Change fuel filter (gas & diesel)
3. Service air filter
4. Tune gas engine
5. Clean & flush radiator & thermostat
6. Inspect fan belt
7. Clean & check battery & store inside
8. Add winter fuel stabilizer
9. Lubricate all control cables

B. Drive Components

1. Check all chains, sprockets, belts & pulleys for wear & proper tension
2. Check shaft couplers for wear
3. Check gear boxes for proper lubrication

C. Hydraulic System

1. Drain reservoir, clean suction screen, change filter, & refill with specified oil
2. Inspect all hydraulic hoses for leaks, cracks and deterioration
3. Inspect all valves, cylinders, motors & fittings for leaks
4. Clean hydraulic coolers

D. Trailer (if so mounted)

1. Inspect tires
2. Pack wheel bearings
3. Inspect hitch, hitch bolts, safety chains & breakaway switch
4. Check brakes- adjust or replace

E. Lubricate grease fittings with hand gun only

F. Check all guards & safety decals. Replace if necessary

G. Restock tool kit with any missing items

H. Restock spare parts bin

I. Inspect the overall machine for structural wear & damage. Tighten loose fasteners

J. Store machine inside or protect as best as possible



All Machine Winterizing